


2.3 How to Connect with PC

When connecting with the personal computer, prepare the optional cable assy MJ-A7SPF0007-050 and D-sub 9 pins plug (local supply), and connected them as follows.



MJ-A7SPF0007-050 cable connection for PC