



- PANEL TOGGLE SW. TO PREVENT ACCIDENTAL ACTIVATION.
- IDIOT LGT. WILL NOW SHOW WHEN C.B. IS ON. PREVIOUSLY SHOWN WOULD HAVE BEEN ON ALWAYS.
- C.B. BEST MOUNTED WITHIN 7" OF SUPPLY.
- SOL. CLOSE TO WINDLASS USE THE WINDLASS GRD. TERM. OR USE A POWER POST.

### ADDED

- MOM. SW. AT WHEEL STATION FOR ALTERNATE CONTROL.
- FUSE BEFORE CONTROL SWITCH AT PANEL.